

Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
1AG(amp), AGA(amp)	301(amp)				
213					
216(amp)					
226(amp)					
263(amp)					
3AB(amp), ABC(amp)	314(amp)	GAB(amp)			
3AG(amp), AGC(amp), GLH(amp), MBW (amp), MMB(amp), MTH(amp)	311(amp), 312 (amp)	GGC(amp), GGL (amp), GTH(amp)			
4164					
4AB(amp), ABS(amp)					
4AG(amp), AGS(amp)					
5AB(amp), ABU(amp), AGU(amp), BAF (amp), BAN(amp)	512(amp), BLF (amp), BLN(amp)	GGU(amp), OTM (amp)	MOF(amp), MOL(amp)		
5AG(amp), 5AB(amp), ABU(amp), AGU (amp), BAF(amp), BAN(amp)	512(amp), BLF (amp), BLN(amp)	GGU(amp), OTM (amp)	MOF(amp), MOL(amp)		
616					
663					
70N-10A	70N	70N			
7AG(amp), AGW(amp)	303(amp)				
8AG(amp), AGX(amp), MJB(amp), MJW (amp), MKB(amp)	361(amp), 362 (amp)	GGX(amp)			
ABC(amp)	314(amp)	GAB(amp)			
ABS(amp)					
ABU(amp), BAF(amp), BAN(amp)	BLF(amp), BLN (amp)	OTM(amp)	MOF(amp), MOL(amp)		
ACF(amp)					
ACH(amp)					
ACK(amp)	CCK(amp)	ACK(amp)	ECK(amp)		
ACL(amp)	CCL(amp)	ACL(amp)	ECL(amp)	CCL(amp) [30-100A]	
ACO(amp)					

Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
ACT(amp)					
ADD(amp) to AFZ(amp)					
AF(amp)					
AFJ(amp)					
AFS(amp)					
AFX(amp)					
AFZ(amp)					
AGA(amp)	301(amp)				
AGC(amp), MMB(amp)	311(amp), 312(amp)	GGC(amp)			
AGC-V	318(amp)	GGC-V			
AGS(amp)					
AGU(amp), ABU(amp), BAF(amp), BAN(amp)	512(amp), BLF(amp), BLN GGU(amp), OTM (amp)	GGU(amp), OTM (amp)	MOF(amp), MOL (amp)		
AGW(amp)	303(amp)				
AGX(amp), MKB(amp)	361(amp), 362(amp)	GGX(amp)			
ALS(amp), AFX(amp)		ALS(amp)	AOK(amp)		
ANL(amp)	CNL(amp)	CNL(amp)	ENL(amp), ENLE (amp)		
ANN(amp)	CNN(amp)	CNN(amp)	ENN(amp), ENNE (amp)		
ARD(amp) to ASX(amp)					
ATC(amp)	257(amp), ATO(amp)	AF(amp)			
AX1(amp), AX1B(amp), GMT(amp), GMT(amp)A	401(amp), 481(amp)	GMS(amp)			
AX1B(amp), AX1(amp), GMT(amp), GMT(amp)A	401(amp), 481(amp)	GMS(amp)			
BAF(amp), BAN(amp)	BLF(amp), BLN(amp)	OTM(amp)	MOF(amp), MOL (amp)		
BAN(amp)	BLN(amp)		MOF(amp)		
BBS(amp), KTQ(amp)	BLS(amp), KLQ(amp)	SBS(amp)	EBS(amp), KEG (amp)		
BCA(amp) to BTX(amp)					

Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
BRB(amp)					
C(amp)	332(amp), C(amp)				
CAB(amp) to CAJ(amp)					
CGL(amp)		FES(amp)			
DLN-R(amp), FRN-R(amp)	FLNR(amp)	TR(amp)R	ECNR(amp)	CRN-R(amp)	
DLS-R(amp), FRS-R(amp)	FLSR(amp)	TRS(amp)R	ECSR(amp)	CRS-R(amp)	
FBP(amp) [0-30A], FWP(amp)	L70S(amp)	A70P(amp), A70QS(amp)			
FM01(amp)					
FNA(amp)	FLA(amp)	GFN(amp)	MID(amp)		
FNJ(amp)					
FNM(amp) [0-10A]	FLM(amp)	TRM(amp)	MEN(amp)		
FNM(amp) [12-15A], FNM(amp) [0-10A]	523(amp), FLM(amp)	TRM(amp)	MEN(amp)		
FNM(amp) [20-30A], FNM(amp) [0-10A], FNM(amp) [12-15A]	523(amp), FLM(amp)	TRM(amp)	MEN(amp)		
FNQ(amp), FNQ-R(amp)	FLQ(amp), KLDR(amp)	ATQ(amp), ATQR(amp)	MEQ(amp)		
FNQ-R(amp)	KLDR(amp)	ATQR(amp)			
FNW(amp)					
FRN(amp), DLN-R(amp), FRN-R(amp)	FLN(amp), FLNR(amp)	TR(amp), TR(amp)R	ECN(amp), ECNR(amp)	CRN(amp), CRN-R(amp)	
FRN-R(amp), DLN-R(amp)	FLNR(amp)	TR(amp)R	ECNR(amp)	CRN-R(amp)	
FRS(amp), DLS-R(amp), FRS-R(amp)	FLS(amp), FLSR(amp)	TRS(amp), TRS(amp)R	ECS(amp), ECSR(amp)	CRS(amp), CRS-R(amp)	
FRS-R(amp), DLS-R(amp)	FLSR(amp)	TRS(amp)R	ECSR(amp)	CRS-R(amp)	
FWA-(amp)A [70-1000A], FWA-(amp)B [70-1000A]	L15S(amp) [70-800A]	A15QS(amp)-4			
FWA-(amp)A10F [5-30A]	L15S(amp) [1-30A]	A15QS(amp)-2			
FWA-(amp)A21F [35-60A]	L15S(amp) [35-60A]	A15QS(amp)-1			
FWA-(amp)AH		A13X(amp)-128	RFA(amp) [1000-4000A]		
FWA-(amp)B [70-1000A], FWA-(amp)A [70-1000A]	L15S(amp) [70-800A]	A15QS(amp)-4			

Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
FWH(amp)	L50S(amp)	A50P(amp), A50QS(amp)	REV(amp)		
FWP(amp), FBP(amp) [0-30A]	L70S(amp)	A70P(amp), A70QS(amp)			
FWX-(amp)A	L25S(amp) [35-800A]	A25X(amp)4, A30QS(amp)-4			
FWX-(amp)A14F	L25S(amp) [1-30A]	A25X(amp)1 [10-30A], A25X(amp)1 [1-9A], A30QS(amp)-1			
FWX-(amp)AH		A25X(amp)128, A30QS(amp)-128			
GBA(amp)	336(amp)	3ABSRI(amp)			
GBB(amp)	322(amp)		GBB(amp)		
GBC(amp)	GBC(amp)				
GDA(amp)	216(amp)	GSD(amp)			
GDA-V(amp)	216(amp)XE, 266(amp)	GSD-V(amp)			
GDB(amp)	217(amp)	GSB(amp)			
GDB-V(amp)	217(amp)XE, 227(amp)	GSB-V(amp)			
GDC(amp)	218(amp)	GDG(amp)			
GDC-V(amp)	218(amp)XE, 228(amp)	GDG-V(amp)			
GJU(amp), GMA(amp) [0-3A], GMA (amp) [3.15-15A]	235(amp) [0-3A], 235 (amp) [4-6A]	GGM(amp) [0-3A], GGM(amp) [10-15A], GGM(amp) [4-8A]			
GJV(amp), AGC-V	318(amp)	GGC-V, GGI(amp)		RGJV	
GKB(amp), 70N-10A	70N	70N			
GLD(amp)	334(amp)				
GLH(amp), AGC(amp), MBW(amp), MMB(amp)	311(amp), 312(amp)	GGC(amp), GGL(amp)			
GLN(amp), MCR	251, 252(amp), 256 (amp)	GSR-V			
GLQ(amp)					
GLR(amp)	LGR(amp)	SLR(amp)			
GLX(amp)		GLR(amp)-V			
GMA(amp) [0-3A]	235(amp) [0-3A]	GGM(amp) [0-3A], GGM(amp) [10-15A]			
GMA(amp) [3.15-15A], GMA (amp) [0-3A]	235(amp) [0-3A], 235 (amp) [4-6A]	GGM(amp) [0-3A], GGM(amp) [10-15A], GGM(amp) [4-8A]			

Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
GMA-V(amp) [0-3A]	235(amp)XE [0-3A], 236(amp) [0-3A]	GGM-V(amp) [0-3A], GGM-V(amp) [10-15A]			
GMA-V(amp) [3.15-15A], GMA-V(amp) [0-3A]	235(amp)XE [0-3A], 235(amp)XE [4-6A], 236(amp) [0-3A], 236(amp) [4-6A]	GGM-V(amp) [0-3A], GGM-V(amp) [10-15A], GGM-V(amp) [4-8A]			
GMF(amp)	LMF(amp)	SMF(amp)			
GMQ(amp)					
GMT(amp), GMT(amp)A	401(amp), 481(amp)	GMS(amp)			
GMT(amp)A, GMT(amp)	401(amp), 481(amp)	GMS(amp)			
GMW(amp)		FAMC(amp)			
GRF(amp), GMF(amp)	LMF(amp)	SMF(amp)			
GRR(amp)					
HAF(amp)					
HAG(amp)					
HBO(amp)	CBO(amp)		OBH(amp)		
HC(amp), CGL(amp)		FES(amp)			
HKL(amp)	344404, 344405				
HKP					
HLQ(amp)					
HLR	LHR	SHR			
HPF	571007	GPM-S			
HPS		GPM-B			
HR	155	SFRT			
HRK	150145	SFRG			
HSK(amp)					
HTB-22I	3453LF2				
HTB-42I	342012	GPM-G			
HVA(amp)					

Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
HVB(amp)					
HVJ(amp)					
HVL(amp)					
HVR(amp)					
HVT(amp)					
HVU(amp)					
HVW(amp)					
HVX(amp)					
IBM(amp) , 70N-10A, GKB (amp)	70N	70N			
JCK(amp)R		A240R-(amp)R			
JCK-A(amp)R		A240R-(amp)R-HS			
JCM(amp)					
JCP(amp)					
JCW(amp)					
JHC(amp) , LPJ(amp), LPJ (amp)SP	JTD(amp), JTD(amp)ID	AJT(amp), AJT(amp) Smart Spot			
JJN(amp)	JLLN(amp)	A3T(amp)	TJN(amp)		
JJS(amp)	JLLS(amp)	A6T(amp)	TJS(amp)		
JKS(amp)	JLS(amp)	A4J(amp)	JCL(amp)		
KAA(amp) , FWA-(amp)A10F [5-30A], KAW(amp)	KLA(amp) [1-30A], KLW(amp), L13S(amp) [1-30A], L15S(amp) [1-30A]	A13X(amp)-2, A15QS(amp)- 2	RFA(amp) [1 -30A]		
KAB(amp) [1-30A] , FWX- (amp)A14F, KAX(amp) [1- 30A]	KLB(amp) [1-30A], L25S(amp) [1 -30A]	A25X(amp)1 [10-30A], A25X (amp)1 [1-9A], A30QS(amp) -1	RFN(amp) [1 -30A]		E25S(amp) [1- 30A]
KAB(amp) [35-800A] , FWX- (amp)A, KAX(amp) [35- 800A]	KLB(amp) [35-800A], L25S(amp) [35-800A]	A25X(amp)4, A30QS(amp)-4	RFN(amp) [35-800A]		E25S(amp) [30- 999A]
KAC(amp)	KLC(amp)	A60X(amp) type 4K	RFC(amp)		
KAF(amp)					
KAF-C(amp)					
KAG(amp) , FWX-(amp)AH		A25X(amp)128, A30QS(amp) -128	RFN(amp)HP		E25S(amp) [1000-1200A]

Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
KAJ35-60(amp)			RFJ35-60		
KAW(amp), FWA-(amp)A10F [5-30A], KAA(amp)	KLA(amp) [1-30A], KLW(amp), L13S(amp) [1-30A], L15S(amp) [1-30A]	A13X(amp)-2, A15QS(amp)-2	RFA(amp) [1-30A]		
KAX(amp) [1-30A], FWX-(amp)A14F, KAB(amp) [1-30A]	KLB(amp) [1-30A], L25S(amp) [1-30A]	A25X(amp)1 [10-30A], A25X(amp)1 [1-9A], A30QS(amp)-1	RFN(amp) [1-30A]		E25S(amp) [1-30A]
KAX(amp) [35-800A], FWX-(amp)A, KAB(amp) [35-800A]	KLB(amp) [35-800A], L25S(amp) [35-800A]	A25X(amp)4, A30QS(amp)-4	RFN(amp) [35-800A]		E25S(amp) [30-999A]
KAZ(amp)		T1600	RFZ(amp)		
KBC(amp)	L60S(amp)	A60X(amp), A60X(amp)-4	RFS(amp)		
KBH(amp), FWH(amp)	L50S(amp)	A50P(amp), A50QS(amp)	REV(amp)		
KBP(amp), FBP(amp) [0-30A], FWP(amp)	L70S(amp)	A70P(amp), A70QS(amp)	RFL(amp)		
KC(amp)					
KD(amp)					
KGA(amp)					
KGC(amp)					
KLA(amp) to KLF(amp)					
KLP(amp)			DCL(amp)		
KLU(amp), KRP-C(amp), KRP-C(amp)SP	KLLU(amp), KLP(amp), KLPC(amp)	A4BQ(amp), A4BT(amp), A4BY(amp)	LCL(amp), LKU(amp)	CLU	
KP(amp)					
KRP-C(amp), KRP-C(amp)SP	KLPC(amp)	A4BQ(amp)	LCL(amp)		
KRP-C(amp)SP		A4BQ(amp)			
KRR(amp)					
KTE(amp), KTJ(amp)					
KTJ(amp), KTE(amp)					
KTK(amp), KTK-R(amp)	KLK(amp), KLKR(amp)	A6Y(amp)type2, ATM(amp), ATM-R(amp)	HCLR(amp), MCL(amp)		
KTK-R(amp)	KLKR(amp)	ATM-R(amp)	HCLR(amp)		
KTN(amp)	KLN(amp)	A2K(amp)	NCL(amp)	CTN (amp)	
KTN-A(amp) canadian					

Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
KTN-R(amp)	KLNR(amp)	A2K(amp)R	NCLR(amp)	CTNR(amp)	
KTQ(amp)	KLQ(amp)		KEG(amp)		
KTS(amp)	KLS(amp)	A6K(amp)	SCL(amp)		
KTS-R(amp)	KLSR(amp)	A6K(amp)R	SCLR(amp)		
KTU(amp)					
LAA(amp)					
LAA-F(amp)					
LAR(amp)					
LHA(amp)					
LKB(amp)					
LKC(amp)					
LKI(amp)					
LKN(amp)	LKN(amp)	RL(amp)	ELNE(amp)		
LKO(amp)					
LKS(amp) , KLU(amp), KRP-C(amp), KRP-C(amp)SP, LKU(amp)	KLL(amp), KLLU(amp), KLP(amp), KLPC(amp), LKU	A4BQ(amp), A4BT(amp), A4BY(amp)	LCL(amp), LKU	CLL, CLU	
LKU(amp) , KLU(amp), KRP-C(amp), KRP-C(amp)SP, LKS(amp)	KLL(amp), KLLU(amp), KLP(amp), KLPC(amp), LKU	A4BQ(amp), A4BT(amp), A4BY(amp)	LCL(amp), LKU	CLL, CLU	
LPA(amp) to LPI(amp)					
LP-CC(amp)	CCMR(amp)	ATD-R(amp)	EDCC(amp)		
LPJ(amp) , LPJ(amp)SP	JTD(amp), JTD(amp)ID	AJT(amp), AJT(amp) Smart Spot			
LPJ(amp)SP	JTD(amp), JTD(amp)ID	AJT(amp), AJT(amp) Smart Spot			
LPN(amp)	LLN(amp)	A2D(amp)			
LPN-R(amp)	LLNR(amp)	AT-DE-R			
LPN-RK(amp) , LPN-RK(amp)SP	LLNRK(amp)	A2D(amp)R	LENRK(amp)	LON-RK(amp)	
LPN-RK(amp)SP	LLNRK(amp)	A2D(amp)R	LENRK(amp)		
LPO(amp)					

Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
LPS(amp) , LPS-R(amp)	LLS(amp)	ATS-DE-RLLSR			
LPS-R(amp)	LLS(amp)	ATS-DE-RLLSR			
LPS-RK(amp) , LPS-RK(amp)SP	LLSRK(amp)	A6D(amp), A6D(amp)R	LESRK(amp)		
LPS-RK(amp)SP	LLSRK(amp)	A6D(amp)R	LESRK(amp)		
LRA(amp) to LRU(amp)					
MBB(amp)					
MBO(amp)					
MBW(amp) , AGC(amp), MMB(amp)	311(amp), 312(amp)	GGC(amp)			
MCR	251	GSR-V			
MD(amp)	3425(amp)				
MDA(amp)	326(amp)	GSA(amp)			
MDC(amp)					
MDF(amp)					
MDL(amp) , MDQ(amp), MDV(amp), MDX(amp)	313(amp), 315(amp)	GDL(amp), GDV(amp)			
MDL-V(amp)	315(amp)				
MDM(amp)					
MDQ(amp) , MDL(amp), MDV(amp), MDX(amp)	313(amp), 315(amp)	GDL(amp), GDV(amp)			
MDR(amp)					
MDV(amp) , MDL(amp), MDQ(amp), MDX(amp)	313(amp), 315(amp)	GDL(amp), GDV(amp)			
MDX(amp) , MDL(amp), MDQ(amp), MDV(amp)	313(amp), 315(amp)	GDL(amp), GDV(amp)			
MGB(amp)					
MIC(amp) , MIJ(amp)					
MIJ(amp) , MIC(amp)					
MIN(amp)	1812(amp)		MIDR(amp)		
MIS(amp) , MS(amp)	473(amp)				

Bussmann	Littelfuse	Gould / Ferraz / Shawmut	Edison / Bullet	Cefco	Economy
MJB(amp) , AGX(amp), MJW(amp), MKB(amp)	361(amp), 362(amp)	GGX(amp)			
MJW(amp) , AGX(amp), MJB(amp), MKB(amp)	361(amp), 362(amp)	GGX(amp)			
MKB(amp) , AGX(amp)	361(amp), 362(amp)	GGX(amp)			
MMB(amp)					
MS(amp) , MIS(amp)	473(amp)				
MTH(amp) , AGC(amp), GLH(amp), MBW(amp), MMB(amp)	311(amp), 312(amp)	GGC(amp), GGL(amp), GTH(amp)			
N(amp)					
NAA(amp) to NAM(amp)					
NO.263				CFR-263	
NO.2642				CFR-642	
NO.2664				CFR-264	
NON(amp)	NLN(amp)	OT(amp)	KON(amp)	10KOTN(amp), 50KOTN (amp) [0-60A]	
NOS(amp)	NLS(amp)	OTS(amp)	KOS(amp)	50KOTS(amp) [0-60A]	
ODA(amp) to OWZ(amp)					
REN(amp)	RLN(amp)	RF(amp)	ERN(amp)	R(amp)	
RES(amp)	RLS(amp)	RFS(amp)	ERS(amp)		
RHA(amp) to RRU(amp)					
S(amp)	S(amp), SLO(amp), SOO(amp)		S(amp)		
SA(amp)	SAO(amp)				
SC(amp)	SLC(amp)	AG(amp)			
SCY(amp)					
SFE(amp)	307(amp), SFE(amp)				
SKA(amp)					
SKG(amp)					
SL(amp)					